



















# FURNI-O-LED-BS-03



## Warning instructions:

1. Assembly should to be carried out by a competent adult only.
2. Regularly check all parts firmly fixed to ensure the furniture for safe use.
3. Wipe clean only.
4. The warning sticker on the furniture is a mandatory requirement in Australia, and it can be removed by wet cloth.



 Φ6*38mm		 Φ15*11mm		 Φ8*40mm		 ST3.5*35mm		 ST3.5*14mm		 ST4*25mm		 M6*15				
B	34 PCS	C	34 PCS	D	8 PCS	E	14 PCS	F	32 PCS	G	8 PCS	H	30 PCS	J	4 PCS	
						 N1 N2						 ST3*12mm		 LED TAPE		
K	2 PCS	L	2 PCS	M	4 PCS	N	6 PCS		Q	3 PCS	S	4 PCS	T	8 PCS	U	1 PCS

# Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools.  
Do not use power tools.



Identify and lay out all of the components before you begin assembly.



Do not fully tighten all screws until step/  
process finished.

## Useful Information


! Never use power tools, they can damage your components or hardware if used incorrectly.




! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.




5





					
S	4 PCS	T	8 PCS	U	1 PCS


7


Front view



			
C	8 PCS	D	8 PCS


6




	
C	2 PCS


7

Back view







	
C	12 PCS


2 Drawers






8


			
15*11mm	ST3.5*35mm	ST3.5*14mm	N2
C	8 PCS	E	8 PCS
F	8 PCS	N2	4 PCS





10





					
ST3.5*14mm					
F	2 PCS	J	2 PCS	K	2 PCS




9



			
15*11mm	ST3.5*35mm	ST3.5*14mm	N2
C	4 PCS	E	4 PCS
F	4 PCS	N2	2 PCS

11



					
ST3.5*35mm					
E	2 PCS	J	2 PCS	L	2 PCS

## LED light

If you can't let the lights work successfully, please check the following:

1. Please check the direction of the connect, try it in the opposite direction, according to the following picture.
2. Please check the remote control, it need you to tear down the plastic septum before use it.
3. Don't let the remote control too far from the receiver, make sure there is no obstruction between them.

